




# Synchronous Buck Converter




# Sync-Buck State Plane




# Sync-Buck ZVS Condition

# Sync-Buck State Plane (Ring out)



# Sync-Buck State Plane – ZVS

# Sync-Buck Complete State Plane



# State Plane Solution: Intervals 1 & 2

# State Plane Solution: Intervals 3 & 4



# State Plane Solution: Averaging Step

# Normalized Period